

Congratulations on the purchase of your NiteSite product! Before you start to use the NiteSite system please carefully read these instructions to enjoy optimum performance and a long service life.

There are three products in the spotting adaptor range for you to enjoy. The **XE**, **XW** and **XV**. Please read the relevant information regarding your product purchase contained in this instruction manual. NiteSite spotting adaptor product's viewing ranges expressed are dependent on the spotting scope and weather conditions.

Intended use

The NiteSite products are add on devices for use with an existing scope. They are also for use in daylight. During darkness the NiteSite products will achieve a night vision identification range of up to 500 metres depending on the model purchased, weather conditions and optic.

NiteSite Ltd does not bear responsibility for the use of this product in countries or territories where the law prohibits its use. It is the sole responsibility of the operator to comply with the laws and regulations of the country or territories where the NiteSite add on devices are used.

Operating instructions

Step 1

Place the Saddle bracket round the spotting scope, feed the velcro ribbon through the saddle buckle and place the strap back on its self so that the saddle is firmly in place on top of the spotting scope

Step 2

Slide the illuminator module into the "T" slot on the saddle bracket.

Step 3

Fit the spotting scope to the NiteSite aluminium bracket using the fixing screw provided. (spotting scope bracket and fixing screws purchased separately)

Step 4

Push the flexible sleeve over the eye piece of the spotting scope. Push the camera in to the flexible sleeve then fix the camera to the aluminium bracket. Make sure the camera and sleeve are fixed so that the camera module is concentrically viewing down the spotting scope eye piece.

Step 5

Fit the battery pack in place (the XE model comes with a 6000 mAh battery in a pouch that must be fitted to the spotting scope and not the flexible sleeve.)

Step 6


Connect the illuminator module to the camera module

Step 7


Connect the battery to the camera module and switch on the NiteSite system with the button on the back of the camera module

Click on your model below to see the respective products **kit contents**






Flexible sleeve mounted onto the camera module




- 1** LED infra-red (IR) illuminator intensity dimming control knob
- 2** Illuminator module - Infra-red protective lens cover.
3.5" screen.
connecting cable.
- 3** XV, XW, XE battery (information on page 5)
- 4** Saddle bracket - The tough plastic bracket with a rubber protective strip comes with a velcro through strap to secure the illuminator module to the spotting scope.
- 5** The torch mount is used to hold the torch clamp accessory (sold seperately.)
- 6** Spotting scope (not supplied.)
- 7** Spotting scope bracket (sold seperately.)
- 8** Sleeves are flexible enough to stretch over most round eye piece. Smaller sleeve may need softening in hot water for larger eye pieces
- 9** Camera module - infra-red (IR) camera, 12-volt DC power supply socket.



Torch clamp



The torch clamp comes in two sizes, 30mm and 1 inch (25mm). For torches larger see the universal clamp. The clamp comes supplied with the locking clip.



Spotting scope bracket

The bracket is designed to be used with the night vision adaptor range for spotting scopes. It is fully adjustable. The bracket comes with the 'T' slot torch mount.

The Camera module



The camera module will require adjustment prior to use. This will guarantee that the scope reticle is in focus when viewed on the LCD screen. The focal distance is factory set, this will usually allow focus to be achieved within a couple of turns of the abrasive ring anti-clockwise.


This should be done during daylight or in a well lit area.

Focusing the camera module will be achieved within two or three anticlockwise revolutions of the lens. Continuing to turn the lens more than 10 full revolutions anticlockwise may result in the lens coming out from the lens mount. Turning the lens anti-clockwise decreases the range of the focal point. Turning clockwise increases it.

The NiteSite system functions in darkness with the use of infra-red light emitted from the illuminator module. In darkness the NiteSite system relies on the camera module receiving as much infra-red light as possible.

Some spotting scope manufacturers have a coating that may reduce infra-red light passing through the spotting scope optic. This coating improves the image visibility at low ambient light levels. The NiteSite system is not as effective with spotting scope lenses that have such coatings. Always check the spotting scope manufacturers instruction details prior to fitting the NiteSite system to ensure you get the best results from the product.

Ferrite installation




2a Place the LCD screen & illuminator module cable into the ferrite approximately 120mm from the end of the right-angle plug.

2b With the cable in place carefully close the ferrite over the cable so that the ferrite snaps together.

This device complies with part 15 of the FCC rules.

Anti glare filters




3a Use tabs to separate the filter from the backing


If during use you find the LCD screen glare too bright, adjust the LED infra red intensity to a lower setting. This will reduce glare considerably when using the equipment at closer ranges. Additionally, an LCD screen anti-glare filter pack is included in the NiteSite kit which can be placed on the LCD screen to suit you. There are five filters in a pack. The anti-glare filters can reduce the range of the NiteSite product. The darker you make the screen the greater chances of reducing visibility at range.

2000 mAh battery (**XV**)

4a




4b




4a Scope mounted battery - The lithium-ion battery can be fitted on the scope sleeve during use. The typical runtime for this product is 4 hours on half IR, depending on which product that it is used with. The battery has a Velcro strap for mounting to the scope. Never take apart the lithium-ion battery

4b Feed the Velcro strap through the strap points on both sides of the battery case, down one side and up through the other side so that the Velcro strap is under the back of the battery. Place the battery in position on the scope sleeve and feed the strap round the scope sleeve and through the buckle. Now double back the Velcro strap under the scope sleeve and pull tight.

4000 mAh battery (**XW**)



6000 mAh battery (**XE**)



Battery chargers

The battery charger comes with a compatible mains pin configuration for your region. To charge the lithium-ion battery, the battery charger must be connected to the mains wall socket. Once the green light is on simply connect the NiteSite lithium-ion battery pack DC plug into the charger DC socket. The lithium-ion battery chargers green light will change to red. The red light indicates that the battery is correctly connected and that the battery is being charged. The indicator light will turn green once the lithium ion battery is fully charged.

Charging times will vary, depending on the type of battery pack and its charged condition. The lithium-ion battery is supplied in a discharged condition and must be fully charged before use.

Always connect the correct lithium-ion battery charger to the correct lithium-ion battery supplied in the kit. Please check you have the correct charger by checking the label located on the battery charger. If in doubt please contact customer services

To prevent potential leakage, overheating or explosion of the battery please be advised of the following precautions.

- Only use the NiteSite supplied lithium-ion battery charger.
- Do not dispose of the battery into an open fire
- Do not immerse in water. Always store in a cool dry environment, away from any metal objects such as pins, nails, keys, jewellery, coins etc.
- Do not leave near a heat source, such as a fire or heater.
- Do not connect the battery directly to an electrical socket outlet.
- Do not short out the battery cables or trap the cable causing a short circuit.
- Do not transport the battery with any metal objects described above.
- Do not strike or throw against hard surfaces.
- Do not pierce the battery with any sharp object.

Caution!

- Do not leave the battery in direct sunlight for prolonged periods of time.
- Do not use in a location where static electricity is evident or the safety circuitry may be damaged.
- Should the battery electrolyte get into the eyes due to leakage do NOT rub the eyes! Rinse with copious amounts of clean water and seek medical attention immediately. Failure to do so may result in permanent damage to the eyes or loss of sight.
- If the battery gives off an odour, generates heat, becomes mis-shaped, or abnormal during use, recharging or in storage, immediately remove the battery pack and place it in a contained vessel such as a metal box, before contacting customer services.
- In case the battery connector is contaminated with debris of any kind during use clean with a dry cloth. Otherwise power failure may occur due to a poor connection from the battery to the NiteSite or to the battery charger.
- Do not use abrasives or solvents to clean the connector plug or battery case.
- Discarded batteries may catch fire so always tape over the battery terminals before disposal.
- Do not take the battery case apart or tamper with the battery pack.

Care and maintenance

After each use and during transport, store the NiteSite equipment in the carry case provided.

Take care not to damage the connecting cables during use. Short circuiting the battery cables could cause burns and fire.

Always keep the battery in the pouch provided. Always fix securely in place during use, utilising the stock mount pouch or Velcro fixings provided. Belt mounted battery pouches are available.

Wipe any debris using a soft moist cloth. Do not use cleaning agents of any kind and always disconnect the battery before cleaning the NiteSite equipment.

To get the most out of the NiteSite equipment, keep the LCD screen & infra-red illuminator front lens clean and free from debris.

The NiteSite equipment is not water proof, only shower proof. Always cover the equipment in rainy conditions.

Safety Information

Never look directly into the infra-red illuminator. The unit can emit very high concentrated non-visible infra-red light which can be hazardous to the human eye. Ensure all relevant legislation relating to safe use of the product is followed.

Persons using the NiteSite equipment under the age of 16 must be supervised by an adult.

Do not attempt to make any repairs to the NiteSite equipment as this will void any guarantee and could cause personal injury and may cause further damage to the NiteSite equipment.

Do not store any part of the NiteSite equipment near open flames or other forms of excessive heat.

The NiteSite equipment is made of durable ABS polymer, under excessive heat this could be compromised.

NiteSite users should adhere to safe working practices.

General disposal

UK: Waste electrical products should not be disposed of with household waste. Separate disposal facilities exist. For your nearest facilities, please contact your local authority for details.

Dispose of batteries in an environmentally friendly way.

Certain regions may regulate the disposal of batteries. Please consult your local authority.

In EC countries batteries must be recycled according to guideline 91/157/EEC

NiteSite guarantee

Your new NiteSite equipment comes with a 24 month guarantee protecting you against electrical and mechanical breakdown. Please see terms and conditions below. There is a 12 month guarantee on battery packs.

It is important to register the purchase of your product in order to ensure that you receive prompt and efficient assistance in the event of it requiring attention during the guarantee period.

NiteSite guarantee conditions

We at NiteSite undertake that if within 24 months of the date of purchase the NiteSite equipment or any part thereof (excluding batteries) proved to be defective by reason only of fault of workmanship or materials, we will, at our discretion repair or replace the same FREE OF ANY CHARGE for labour, materials on condition that:

- 1) You are the original purchaser and not an assignee or subsequent purchaser of the equipment.
- 2) The product has been used in accordance with the manufacturers operating and maintenance instructions.
- 3) The product has not been serviced, maintained, repaired, taken apart or tampered with by any persons not authorised by NiteSite.
- 4) All service work under this guarantee must be undertaken by the NiteSite customer service department.
- 5) Any product or defective part replaced shall become the property of NiteSite.

Please Note

- A) This guarantee is in addition to your statutory and other legal rights.
- B) NiteSite will return product by courier within 28 days of receipt.
- C) The company's liability under this warranty is limited to the said repairs or replacement and shall under no circumstances extend to any financial losses alleged to have been suffered by the claimant.
- D) In the event of repairs or replacement being made under the terms of this warranty in the circumstances where the opinion of the company the defect has not been caused by the company's materials or workmanship then the company reserves the right to charge the claimant at its current hourly rates and list prices in respect of any employees time and any replacement parts.
- E) No authority has been given to any person, firm or company, to vary the terms of this guarantee.

The guarantee does not cover the following:

- 1) Damage resulting from transportation.
- 2) Damage resulting from improper use or neglect.
- 3) Consequential damage resulting from unauthorised repair work.
- 4) Accidental damage.
- 5) Damage resulting from modification attempts